



### Class 100 6 Stage Sterile Clean

- Stage 1** Vacuum all surfaces with Hepa-filtered Vac.
- Stage 2** Particle roll all surfaces with rollers.
- Stage 3** Wash all surfaces with sterile Klercide Neutral Detergent.
- Stage 4** Rinse all surfaces with sterile water.
- Stage 5** Wash all surfaces with sterile Klercide B disinfectant.
- Stage 6** Rinse all surfaces with sterile water.

### Equipment/Chemical List

<u>Product Name</u>	<u>Product Code</u>
Guardline De Ionised Water 0.2 Micron Filtered	71919 (S)
Klerwipe CR Sterile IPA Tub Wipe	WPK 3900
Microfibre Flat Mophead	DM-F4OL-L
Klercide Sterile CR Bactericidal B Cleaner	KCR 4242
Klercide Sterile CR Biocide Y Concentrate	KCR725
Sterile IPA 70/30 with delivery system	62140S
Sterile Wipeguard wipes	706069X9(S)
Sterile Klercide Neutral Disinfectant	70813(S)
Tyvek Coverall	74936

All products supplied my Guardline/Lynbond.